UC1 firmware update guide

First, figure out which hardware version you have. In the last tab, called "S1", in the UC1 menu, you will find your hardware version. Here you can find the .bin firmware files, you select the appropriate file based on your hardware version:

For Minco: uc1_upgrade_x.x.x-minco.bin
HW Version 2.x: uc1_upgrade_x.x.x-hw2.bin
Other: uc1_upgrade_x.x.x-hw1.bin

Updating on windows:
1. Turn off the UC1.
2. Press the top button while you see the loading bar. Turn the UC1 on for this.
3. Open the Grimm Audio Control Panel.
4. Click the tab "Firmware Upgrade".
5. Load the .bin file you downloaded earlier.
6. Click "Start Firmware Upgrade".
7. Wait for the update to finish.

Updating on mac or linux:
1. Go to https://update-uc1.grimmaudio.com/firmware/progrimmer/.
2. Download the UC1 Progrimmer installer from the respective folder for your OS.
3. Install the UC1 Progrimmer.
4. Open the UC1 Progrimmer.
5. Make sure your UC1 is on and connected to your computer.
6. Click "Select firmware" and select the .bin file you downloaded earlier.
7. Wait for the update to finish.